

Bead Lock Power Procedure

By Harry Lewellyn 090129

Staun does not supply enough powder for optimum mounting of your new Staun Bead Lock; so go down to the local 99 cent store and buy any bath, baby or talc powder. It all works fine. Now, powder the heck out of everything like this picture shows (neglect the older style air channel), particularly the Beads (the black webbing rings) inside and outside. It does not even hurt to powder the tire near the inside of the bead. The other thing is to use a Windex like product as the tire lube when popping the beads on. Finally, pop the tire on first using the tire valve stem with the tube valve core removed. Now, remove the tire valve core and inflate the Staun to 50 psi and then the tire.

